






# \*\*\* POWERMOUNT-9000S INSTALLATION INSTRUCTIONS \*\*\*

<p><b>1</b></p>  <p>STRING LINE</p> <p>METAL PANEL ROOF SYSTEM</p> <p>MEASURE THE DISTANCE FROM EAVE TO THE FIRST ROW OF POWERMOUNTS AND USE A STRING LINE OVER THE TOP OF THE ROOF PANEL CORRUGATIONS TO ESTABLISH A STRAIGHT GUIDELINE FOR INSTALLATION.</p>	<p><b>2</b></p>  <p>POWERMOUNT-9000S</p> <p>PRE-APPLIED EPDM GASKET</p> <p>METAL PANEL ROOF SYSTEM</p> <p>USE A RAG TO WIPE AWAY ANY EXCESS DIRT AND OIL FROM THE SURFACE OF THE ROOF PANEL. THEN ALIGN THE POWERMOUNT-9000S TO THE STRING LINE AND PLACE ON THE ROOF PANEL AS SHOWN ABOVE.</p>
<p><b>3</b></p>  <p>POWERMOUNT-9000S</p> <p>#14 x 2" STAINLESS STEEL SELF-TAPPING SCREW FASTENERS WITH EPDM WASHERS (2 TOTAL)</p> <p>METAL PANEL ROOF SYSTEM</p> <p>PRE-APPLIED EPDM GASKET</p> <p>SECURE THE POWERMOUNT-9000S BY SCREWING THE (2 TOTAL) SCI SUPPLIED #14 x 2" STAINLESS STEEL SELF-TAPPING SCREW FASTENERS WITH EPDM WASHERS INTO/THROUGH THE PRE-PUNCHED HOLES, THROUGH THE EPDM GASKET, THROUGH THE ROOF PANEL, AND INTO/THROUGH THE ROOF DECK. MAKE SURE TO NOT OVER-TIGHTEN AS YOU RISK STRIPPING THE FASTENER. IF A FASTENER IS STRIPPED, REMOVE AND REPLACE WITH A SIMILAR FASTENER, BUT OF A LARGER DIAMETER.</p> <p><b>NOTE: REFER TO THE FASTENER MANUFACTURERS' RECOMMENDATIONS FOR TORQUE AND WASHER SEATING REQUIREMENTS BEFORE INSTALLATION.</b></p>	<p><b>4</b></p>  <p>POWERMOUNT-9000S</p> <p>METAL PANEL ROOF SYSTEM</p> <p>PRE-APPLIED EPDM GASKET</p> <p>VERIFY THE POWERMOUNT-9000S IS SECURE, STRAIGHT, AND LEVEL. MEASURE AND MARK THE LOCATION OF THE NEXT POWERMOUNT-9000S IN THE SERIES. THEN REPEAT STEPS 2-4 FOR THE REMAINING POWERMOUNT-9000S IN THE SERIES. BE SURE TO FOLLOW THE ARCHITECT'S AND/OR ENGINEER'S REQUIRED SPACING AND/OR LAYOUT, INCLUDING THEIR ADJUSTMENTS FOR FIELD CONDITIONS, IF ANY ARE REQUIRED. A RECOMMENDED LAYOUT CAN BE FURNISHED BY SOLAR CONNECTIONS INTERNATIONAL INC. UPON WRITTEN REQUEST, ONLY.</p> <p><b>NOTE: IF THE POWERMOUNT IS INSTALLED ON NON-SMOOTH SURFACE, THE ENTIRE PERIMETER AROUND THE POWERMOUNT-9000S MUST BE CAULKED TO ENSURE A PROPER WATERTIGHT DETAIL.</b></p>

## POWERMOUNT-9000S INSTALLATION

 <p><b>SOLAR CONNECTIONS INTERNATIONAL</b></p> <p>YOUR PREMIER SOLAR ATTACHMENT SOLUTION</p> <p>220 EXCHANGE DRIVE, UNIT B, CRYSTAL LAKE, IL 60014</p> <p>PHONE: 800.815.7652 WEBSITE: WWW.SOLARCONNECTIONS.COM FAX: 815.455.4367 E-MAIL: INFO@SOLARCONNECTIONS.COM</p>	<p><b>DISCLAIMER</b></p> <p>THE INFORMATION HEREIN IS CONFIDENTIAL AND PROPRIETARY AND IS NOT TO BE DISCLOSED OR DELIVERED TO THIRD PARTIES WITHOUT THE PRIOR WRITTEN CONSENT OF SOLAR CONNECTIONS INTERNATIONAL, INC.</p> <p>SOLAR CONNECTIONS INTERNATIONAL, INC. DOES NOT WARRANT THE INSTALLATION OF ITS PRODUCTS. PRODUCT PERFORMANCE IS DEPENDENT ON THE INSTALLER'S STRICT ADHERENCE TO THESE INSTALLATION INSTRUCTIONS.</p> <p>SOLAR CONNECTIONS INTERNATIONAL, INC. IS NOT A LICENSED ARCHITECT OR ENGINEER, THEREFORE WE STRONGLY RECOMMEND THAT AN ARCHITECT AND/OR STRUCTURAL ENGINEER PROPERLY LICENSED IN THE CITY AND STATE WHERE THE PROJECT IS LOCATED, REVIEW THE CONTEMPLATED LAYOUT TO ENSURE THAT THE BUILDING STRUCTURE CAN WITHSTAND THE PROJECTED SNOW AND/OR WIND LOAD. SOLAR CONNECTIONS INTERNATIONAL, INC. ASSUMES NO LIABILITY THEREFORE.</p>	<p>DRAWN BY: RJH</p> <p>DATE: 9/19/25</p> <p>SCALE: N.T.S.</p> <p><b>1</b></p>